




EPT-4215I-D
TurboHD PTZ Camera
Quick Start Guide

Manual Illustrations and Features

Graphics (screen shots, product pictures, etc.) in this document are for illustrative purposes only. Your actual product may differ in appearance. Your product might not support all features discussed in this document.

Hikvision USA Inc., 18639 Railroad St., City of Industry, CA 91748, USA •
Hikvision Canada, 4848 rue Levy, Saint Laurent, Quebec, Canada, H4R 2P1

Telephone: +1-909-895-0400 • Toll Free in USA: +1-866-200-6690 • E-Mail:
sales.usa@hikvision.com • www.hikvision.com

COPYRIGHT © 2017-2018 Hangzhou Hikvision Digital Technology Co., Ltd.

ALL RIGHTS RESERVED.

IMPORTANT INFORMATION FOR SECURITY

You must carefully read this manual before use and installation of the camera and keep this manual properly.



ATTENTION: Failure to comply with the following instructions may cause serious injury or death.

- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region. Please refer to technical specifications for detailed information.
- This product is designed to be powered by supply unit under IEC60950-1. Please use a power supply 110-240 V 12 ---, 5A (connector with positive central).
- Do NOT connect directly to the power grid for any reason.
- Do NOT connect several devices to one power adapter as adapter overload may cause over-heating or a fire hazard.
- Make sure that the plug is firmly connected to the power socket. When the product is mounted on the wall or ceiling, the device shall be firmly fixed.
- If smoke, odor, or noise rise from the device, turn off the power at once and unplug the power cable, and then contact the service center. The installation should be carried out only by qualified personnel and shall comply with all the rules.



ATTENTION: Failure to comply with the following instructions may cause injury or damage to device.

- Do NOT install the device near heat source such as radiators, vent of stove, or other source of heat.

- Do NOT use the wires under excessive tension or compression loading.
- Do NOT drop the camera or subject it to physical shock.
- Do NOT use aggressive or abrasive detergents to clean body of the device.
- Use only accessories recommended by Hikvision.
- Do not expose the camera directly to high concentrations of X-ray, laser, or UV radiation. The direct exposure may cause permanent damage to the image sensor.
- If the product does NOT work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the camera yourself.

Trademarks Acknowledgement

HIKVISION and other Hikvision trademarks and logos are the properties of Hikvision in various jurisdictions. Other trademarks and logos mentioned below are the properties of their respective owners.

Legal Disclaimer

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, IS PROVIDED "AS IS," WITH ALL FAULTS AND ERRORS, AND HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF THIRD PARTY. IN NO EVENT WILL HIKVISION, ITS DIRECTORS, OFFICERS, EMPLOYEES, OR AGENTS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA OR DOCUMENTATION, IN CONNECTION WITH THE USE OF THIS PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

REGARDING TO THE PRODUCT WITH INTERNET ACCESS, THE USE OF PRODUCT SHALL BE WHOLLY AT YOUR OWN RISKS. HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

SURVEILLANCE LAWS VARY BY JURISDICTION. PLEASE CHECK ALL RELEVANT LAWS IN YOUR JURISDICTION BEFORE USING THIS PRODUCT IN ORDER TO ENSURE THAT YOUR USE CONFORMS THE APPLICABLE LAW. HIKVISION SHALL NOT BE LIABLE IN THE EVENT THAT THIS PRODUCT IS USED WITH ILLEGITIMATE PURPOSES.

IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW, THE LATER PREVAILS.

Getting Started

1. Install the cameras to the mounting location suggested by Hikvision or on the product data sheet.
2. Plug cameras into the DVRs BNC connectors.
3. Connect the camera power cables.
4. Perform operations with the camera such as live view, PTZ, recording, detection setting, etc. See User Manual, which can be downloaded from www.hikvision.com, for detailed information.

NOTE: PTZ control of this camera is achieved using UTC (Up-the-Cable) protocol.

5. Access the camera's OSD menu and PTZ setup by clicking the menu icon in the PTZ control panel, by calling Preset 95, or clicking the **+ IRIS** key.

PTZ Parameter Settings	
Baud Rate	9600
Data Bit	8
Stop Bit	1
Parity	None
Flow Ctrl	None
PTZ Protocol	UTC(Coaxitron)
Address	0
Address range: 0~255	

Copy OK Cancel

6. Set the **PTZ Protocol** field to **UTC (Coaxitron)**.

NOTE: UTC (Coaxitron) is **Hikvision-C Up-the-Coax (UTC)** protocol used exclusively by Hikvision UTC DVRs. This unit will not work with a third-party DVR using the Pelco Coaxitron protocol.

Do not change the default camera DIP switch settings, which are set for Hikvision-C protocol use. For specific DIP switch settings, see the *EPT-4215I-D User Manual*.

TECHNICAL SUPPORT

In case of any problems, immediately contact the local after-sales service authorized by Hikvision.

