


Quick Installation Guide




No.	Description
1	Lens
2	Sun Shield
3	Power Interface
4	Network Interface (PoE)
5	Memory Card Slot Cover
6	Memory Card Slot(Different Models)
7	Reset Button(Different Models)


Installation Steps

1. Memory Card Installation

1) Unscrew the cover on back case to expose memory card slot




2) Insert the memory card into the memory card slot




3)(Optional) To unmount the memory card, push to get it ejected
4) Screw the cover back to the camera

2. Drill 4 screw holes (hole 1 on drill template) and the cable hole in the ceiling/wall




3. Fix the camera to the wall/ceiling with the supplied screws




4. Adjust the surveillance angle

1) Loosen No.1 lock screw to adjust the tilt angle [0° to 100°]
2) Loosen No.2 lock screw to adjust the pan angle [0° to 360°]
3) Loosen No.3 lock screw to rotate the camera [0° to 360°]
4) Tighten the lock screws



Note:

A wrench is supplied to loosen and tighten the screws.



For detailed instructions of further configuration, please refer to the user manual of network camera.