Install the AE20 using the three-point configuration. The surface mount and octagonal box installs are the only opyions in the three-point install. Refer to the following illustration.

Install the cover tamper screw. Refer to illustration below.

3 | Specifications

Dimensions	(HxWxD) 5 in x 6 in x 1.5 in (12 cm x 16 cm x 4 cm)

NOTICE!
Refer to the control panel or module installtion instructions for connecting to the control panel.

CAUTION!
All modules used with this enclosure should be power limited. The total power within the enclosure should be no more that 15 W.

For documentation in your specific language, go to your regional Bosch Security website.

Universal Enclosure
AE20

BOSCH

en   Installation Guide

1 | Overview

This enclosure holds several Bosch and EDM input, output, and receiver modules.

2 | Installation

i **NOTICE!**
Failure to follow the mounting instructions can damage the enclosure.

1. Open by inserting a screwdriver into the two slots.

2. Use the mounting holes when installing to an elecrical box.

| Callout	Description	Callout	Description
1	4 in (10 cm) square	3	Double-gang box
2	Single-gang box	4	3.5 in (9 cm) octagon

i **NOTICE!**
The wall tamper does not function when you install to an electrical box.

3. Install a 3-point module before installing the enclosure to the wall.

Callout	Description
1	Three-point mounting slots

4. Attach to the surface. Refer to the following illustration.

Callout	Description	Callout	Description
1	Surface install holes	2	Wall tamper screw location

i **NOTICE!**
Inserting a screw into the tamper bracket keeps the bracket and AE20 separate when the screw is tightened, or when the AE20 is removed. For proper alignment, insert this screw last.

3 | Attaching

Install a module into the AE20. Refer to the following illustration.